



851 Transport Drive Phone: 219 465 2700
Valparaiso, IN 46383-8432 Web: www.gasleaksensors.com

Innovative Detection Solutions

MADE IN THE USA
WITH GLOBALLY SOURCED COMPONENTS

Distributed by:

Quick-Start Instructions



This is not a substitute for the instruction manual. It is for reference only.

Read and understand the instruction manual before use.

SENSIT® GLT

QUICK-START INSTRUCTIONS

1. Turn on G2-GLT Device and Tablet (for the tablet press and hold the top right button).
2. Wait until G2-GLT displays 'WAITING FOR TRAINER' on screen.
3. Note: If G2-GLT Device has passed 'WAITING FOR TRAINER' screen (Either you have skipped or it has already been connected with application), It will take you directly to the Instrument screen.
4. Launch the GLT application (if it does not auto launch).
5. Tap the "Connect"
6. After the connection has been made, tap either of the two options
7. Training Mode: It will put device in simulation mode and allows trainer to control device (sensors are inactive).
8. Monitoring Mode: It will put device in Normal mode and allows trainer to monitor remotely (sensors are active).
9. The G2-GLT will continue through warm-up and arrive at the work display.
10. The tablet will display the G2-GLT screen with adjustable slide bars if in "training mode" or just the screen if in "monitor mode".

11. The training modules will be displayed simultaneously on the right hand side or bottom side of the screen depending on the orientation of the tablet.
12. Note: If you need to switch the mode, you need to 'Disconnect' and Restart the 'G2-GLT Device'.
13. Note: If any configurations or mode changes on 'G2-GLT Device', please power cycle the G2-GLT and connect to the application again.

